

FIG 1

Salzburg L Convection = mm




FIG 1a

Salzburg L Convection extension base = mm




FIG 1b

Salzburg L Convection + 1 = mm




FIG 1c

Salzburg L Convection / Salzburg L Convection extension base
Salzburg L Convection + 1 = AIR =mm

